



**WARN INDUSTRIES, INC.
INSTALLATION INSTRUCTIONS FOR THE**

**WRANGLER, CHEROKEE AND COMANCHE, FRONT AXLE
WHEEL HUB CONVERSION KIT**

THIS KIT IS NOT INTENDED FOR VEHICLES WITH ABS

**Before starting, New "full-cast" rotors from 1990 or newer Wrangler must be used with this kit, this rotor (ITT #65225 or equivalent) has a .25 thick mounting flange. Do not use the factory style "composite" rotor (.125" thick flange). Rotor pilot hole must be machined to a diameter of $3.575 \pm .015$ to fit the wheel hub. (See figure 1, Page 1)*

As you read these instructions, you will see NOTES, CAUTIONS and WARNINGS. Each message has a specific purpose. NOTES are additional information to help you complete a procedure. CAUTIONS are safety messages that indicate a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. A CAUTION may also be used to alert against unsafe practice. WARNINGS are safety messages that indicate a potentially hazardous situation, which, if not avoided could result in serious injury. CAUTIONS and WARNINGS identify the hazard, indicate how to avoid the hazard, and advise of the probable consequence of not avoiding the hazard. PLEASE WORK SAFELY!

**WARN INDUSTRIES, INC. • 12900 SE CAPPS ROAD • CLACKAMAS, OR 97015-8903(503)
722-1200 • CUSTOMER SERVICE LINE 1-888-722-6730 • FAX (503) 722-3051**




Figure 1. Rotor Machining Diagram

SAFETY PRECAUTIONS



CAUTION



READ INSTRUCTIONS THOROUGHLY BEFORE BEGINNING INSTALLATION.

This sheet provides guidelines to install the WARN Front Wheel Hub Conversion Kit (Figure 3). There are NOTES, CAUTIONS, and WARNINGS which should be followed during installation to avoid possibility of personal injury or damage to the vehicle. During installation, standard safety precautions and equipment should be used where appropriate. Because the skill and experience of the installer and the tools used can vary widely, it is impossible to anticipate all conditions under which this installation is made or to provide cautions for all possible hazards. If your installation varies from the instruction, you must be completely satisfied that your safety or the operation of the vehicle will not be compromised.

NOTE: If you have questions concerning the installation of the Warn Front Axle Wheel Hub Conversion Kit, call our toll-free number (1-888-722-6730) for assistance.

APPLICATIONS

The Warn Front Axle Wheel Hub Conversion Kit is designed to fit Wrangler, Cherokee and Comanche Jeeps.

FEATURES

- Eliminates steering drag caused by front locking differentials in YJ's, TJ's and XJ's
- Exclusive high strength alloy locking hubs to fit new 27 spline outer axle.
- Serviceable bearings and seals.

TOOLS AND MATERIALS NEEDED

Jack	1/2" Drive Socket Set
Jack-stands	4-Lug Socket for Dana 44 (Fig 2)*
Torque Wrench	Safety Goggles
13mm 12 Pt. 1/2" Drive Socket	Shop Rags

*Snap-on PN S8695C or similar




Figure 2. 4-Lug socket.

PARTS LIST (included in kit) (Refer to Figure 3 for Item #)

Item #	Part Name (Qty)	Other P/N
1	Hublocks (2)	37780
2	Axle Retainer (2)	†42768
3	Spindle Washer (2)	†42773
5	Spindle Nut Kit (2)	37545
6	Outer Bearing Cone (2)	*LM501349
7	Outer Bearing Cup (2)	*LM501310
8	Wheel Hub (2)	36891
9	Inner Bearing Cup (2)	*LM102910
10	Inner Bearing Cone (2)	*LM102949
11	Grease Seal (2)	**CR22353
12	Wheel Studs (10)	‡142193
13	Spindle (2)	36893
14	Needle Bearing (2)	†550759
15	Spindle Seal (2)	†36361
16	Thrust Washer (2)	†38106
17	V-Ring Spindle Seal (2)	†38128
18	Seal Shield (2)	36364
19	Outer Axle (2) Using 260X U-Joint	37663
19A	Outer Axle (2) Using 297X U-Joint	37662
20	U-Joint	†5-260X
20A	U-Joint	†5-297X

* AFBMA bearing P/N ** CR Services P/N *** Russell P/N † Spicer P/N ‡ Bendix P/N

NOTE - Item numbers 14-17 replacements can be purchased in kit form, from Spicer using the following part number 706527X.




Figure 3. Front axle wheel hub conversion kit. Parts not included in kit are drawn with dashed lines



WARNING



Raised vehicles can cause falling particles. **WEAR SAFETY GOGGLES.** Falling particles can cause eye injury.



Improperly supported vehicles can fall. **DO NOT USE A JACK TO SUPPORT THE VEHICLE. USE JACK STANDS IN PAIRS TO SUPPORT THE VEHICLE. USE JACKS OR JACK STANDS ONLY ON A HARD, STABLE, AND LEVEL SURFACE. DO NOT EXCEED THE RATED CAPACITY OF A JACK OR JACK STANDS.** An unstable vehicle can fall and cause a crushing injury.

A rolling vehicle can cause jackstands to tip. Before working under vehicle, **VERIFY THAT THE PARKING BRAKE IS SET, THE TRANSMISSION IS IN PARK (AUTOMATIC) OR REVERSE (MANUAL) AND THE REAR WHEELS ARE CHOCKED.** A tipping jackstand or vehicle can cause injury.

DISASSEMBLY

NOTE: The following instructions are for doing one side of the axle. Both sides of the axle can be done simultaneously.

1. Start the engine. Shift the transfer case into one of the 4WD modes. Leave transfer case in the position throughout entire wheel hub conversion installation. This will aid installation of the axle shafts
2. Turn the ignition key OFF. Put transmission in Park (automatic) or Reverse (manual).
3. Set the parking brake and chock the rear wheels.
4. Raise the front end and support it on 2 jack stands.
5. Remove the tire and wheel assembly.



WARNING

Brake pads may contain asbestos. **NEVER CLEAN BRAKE SURFACES WITH COMPRESSED AIR. AVOID INHALING ANY DUST FROM THE BRAKE SURFACE. USE A COMMERCIALLY AVAILABLE BRAKE CLEANING FLUID.** Asbestos has been found to be a cancer causing agent.

6. Remove the caliper and hang it from the frame or suspension with a piece of wire, being careful not to strain the brake hose.
7. Remove 3 bolts retaining the original hub (using 13mm 12pt socket) and bearing assembly. Do not disassemble the bearing assembly from axle shaft. See figure 4. (For location reference only)

NOTE: Refer to your authorized Jeep Technical Service Manual for removal instructions.

8. Remove axle shafts, brake shield, hub and bearing pack. See Figure 4. (For

location reference only)




Figure 4. Exploded knuckle

NOTE: Be careful not to damage inner differential seal.

	WARNING
	Press parts under stress can break. WEAR SAFETY GOGGLES. Broken parts can cause eye injury.

9. Separate the original inner shaft from the outer shaft by removing the u-joint.

NOTE: Refer to your authorized Jeep Technical Service Manual for removal instructions.

10. Install shield to outer axle shaft (both components supplied with kit). See figure 5.




Figure 5. Stub axle and seal shield.

11. Install u-joint and outer axle shaft (both supplied in kit) to inner axle shaft.

12. While supporting axle assembly to keep from pushing loose material into differential, slide axle assembly into differential being careful not to damage the inner seal.
13. Place thrust washer I.D. chamfer side towards Yoke. See figure 3, Flag 16.
14. Place V-seal (thick side towards yoke) on axle shaft. See figure 3, Flag 17.

NOTE: Be sure that factory installed spindle seal is placed cup side, facing away from needle bearing. This seal is held in by grease only.
See figure 3, Flag 15.

15. Clean mating surfaces between steering knuckle and spindle.
16. Place spindle over outer axle shaft and bolt on to steering knuckle. Torque 3 bolt to 75 ft. lbs. See Figure 4.

ROTOR TO WHEEL HUB INSTALLATION

1. Place the brake rotor to the wheel hub aligning the holes. See figure 6.
2. Press the studs into the holes.

NOTE: Make sure head of stud firmly contacts the brake rotor flange




Figure 6. Stud press diagram

BEARING INSTALLATION

1. Inspect inside of wheel hub and clean if necessary. (See Figure 3, Flag 8.)
2. Pack wheel hub inner diameter (Figure 7, Flag 6) with wheel bearing grease.
3. Apply a coating of grease to the inside diameter of the bearing cups.
4. Pack the inner wheel bearing cone (LM102949) with wheel bearing grease. Use a wheel bearing packer if possible. To pack by hand, place a large amount of grease in the palm of your hand and force the edge of the bearing into the grease so that it fills with grease. Continue until the whole bearing is coated with grease. Apply additional grease with fingers.
5. Install packed bearing into cup on inboard side of wheel hub. (Figure 7, Flag 1)
6. Apply additional grease around back side of installed bearing. (Figure 7, Flag 2)

7. Fill large radial seal cavity with grease. Press large radial seal into seat of inboard side of wheel hub. (Figure 7, Flag 2) Seal may protrude slightly from wheel hub.




Figure 7. Bearing and seal installation.

8. Pack outer bearing (LM501349) with grease using the same technique described in step 4.
9. Install outer bearing (Figure 7, Flag 3).

WHEEL HUB INSTALLATION

1. Apply a light coating of grease to the shank of the spindle.
2. Slide wheel hub assembly onto spindle.

NOTE: Keep wheel hub aligned with spindle so bearings don't wedge on spindle.

3. Thread inner nut with pin (Figure 3, Flag 5) on to spindle.

NOTE: Pin on nut should face outboard (Figure 3, Flag 5)

4. Using hub spindle nut socket (Figure 2) and torque wrench, torque nut to 50 ft-lb. Rotate wheel back and forth while tightening the nut. This helps seat the bearings.



WARNING



Excess force can cause tool slippage or breakage and damage to the nut. **DO NOT OVERTORQUE NUTS.** Broken or slipping wrenches can cause eye or other injury.

5. Loosen the nut ½ turn (180 degrees).
6. Re-torque the nut to 3 to 5 ft-lb.

NOTE: All free clearance should be removed from the bearings. If not, repeat procedure.

7. Install lockwasher on spindle. See Figure 3, Flag 5.

NOTE: Align tab on washer with spindle keyway (Figure 3). See Flag 5A and Flag 13A.

NOTE: Pin on inner nut must fit into A slot on washer. If it does not, flip washer over and reinstall (Figure 3, Flag 5)

8. Thread outer nut on spindle. See Figure 3, Flag 5.
9. Torque outer nut to 125 to 150 ft-lb.

INBOARD RETENTION KIT INSTALLATION

NOTE: If necessary, a pry bar can be inserted into the knuckle (universal joints) to hold the axle shaft outboard while installing the axle retention kit.

1. Place splined washer completely onto axle shaft. See Figure 7, Flag 4.
2. Place c-clip on inboard side of axle shaft splines. See Figure 7, Flag 5
3. Reinstall caliper. Refer to you authorized Jeep Technical Service Manual for caliper installation instructions.

HUBLOCK INSTALLATION

1. Lube O-ring seal with ANTI-SEIZE

NOTE: Do not add grease to hublocks.

2. Install Hub assembly (Figure 3, Flag 1) onto wheel hub aligning over wheel studs.
3. Install wheels and tires. Snug lug nuts.

NOTE: Repeat all steps for other side of vehicle.

HUBLOCK CHECK

1. To check for proper engagement, dial both hub-locks to LOCK. Spin one axle.

NOTE: For an open differential, the opposite axle will reverse rotate if the hub-locks are engaging properly. For a locking differential, the drive line and opposite axle will turn if the hub-locks are engaging properly.

2. To check for proper disengagement, dial one hub-lock to FREE and spin the same axle.

NOTE: For a locking differential, if the drive line does not turn and there are no ratcheting sounds, the hub-lock is disengaging properly. For an open differential, if the opposite axle does not turn and there are no ratcheting sounds, the hub-lock is disengaging properly.

3. Repeat steps 1 and 2 for opposite hub-lock.

OPTIONAL - To secure axle shaft engagement permanently you may elect to complete the following.

Step 1 - Remove vacuum actuator from front axle assembly.




Figure - 8

Step 2 - Remove 3 "e-clips" from inside actuator housing as shown in Figure 8. (See Flag 1A, 2A and 3A)

Step 3 - Slide out vacuum actuator form actuator housing. (Figure 8, Flag 5)

Step 4 - Slide brass spacer on to vacuum actuator piston. (Figure 8, Flag 4)

Step 5 - Insert shift fork arm into housing being sure that arm is facing in the correct position. (Figure 8, Flag 2)

Step 6 - Insert vacuum actuator with brass spacer into housing being sure to slide through shift fork. (Figure 8, Flag 4 and 5)

Step 7 - Snap in large "e-clip" on to vacuum actuator housing in area indicated. (Figure 8, Flag 3a)

Step 8 - Extend vacuum actuator piston so that it is fully extended.

Step 9 - Slide brass spacer so that it is against vacuum actuator body.

Step 10 - Insert 1 small "e-clip" so that brass collar is "trapped" between both the vacuum housing and the "e-clip".

Step 11 - Slide engagement arm so that it is against 1" small "e-clip".

Step 12 - Insert 2nd small "e-clip" so that engagement arm is "trapped" between both "e-clips".

Step 13 - Make sure all 3 "e-clips" are seated firmly to prevent them from falling off.

Step 14 - Attach gear engagement ring onto spline in axle.

Step 15 - Reattach assembled locker housing to axle housing being sure that engagement arm is seated firmly onto engagement ring.

Step 16 - Firmly secure mounting bolts to axle housing per Jeep maintenance manual torque specifications..

4. Lift vehicle. Remove jack-stands. Lower vehicle to ground.

5. **Torque** lug nuts per manufacturer's specifications.

WARNING: After 50 miles, re-torque lug nuts to manufactures specifications. Always re-torque lug nuts after hard trail use.

Warn Industries, Inc. ("Warn") warrants parts and labor directly to the first purchaser of each Warn Front Wheel Hub Conversion Kit ("Kit") against defects in material and workmanship appearing under normal use and service for as long as said purchaser owns the Kit (Bearings and seals are not covered). If you discover a covered defect, Warn will, at its option, repair, replace, or refund the purchase price of the Kit, or components, at no charge to you, provided you remove the Kit or components from the vehicle and return them prepaid to the nearest Warn Industries' Factory Authorized Jobber. You can obtain additional information from Warn directly at the address printed below. Please attach to the returned Kit or components, your name, address, telephone number, a description of the problem and a copy of the bill of sale (as proof of original retail purchase). To obtain warranty coverage, it is absolutely necessary that you present proof of purchase acceptable to Warn, such as a copy of the purchase receipt.

This warranty does not apply if the product has been damaged by: accident, abuse, misuse, collision, overloading, or misapplication; or has been improperly: installed, used, serviced, or modified without the written permission of Warn.

Except as expressly stated herein, there are no warranties, express or implied, including implied warranties of merchantability or fitness for a particular purpose. Any implied warranty of merchantability or fitness for a particular purpose which by law may not be excluded is limited in duration to one (1) year from the date of the original retail purchase of this product.

The warranty and the remedies set forth above are exclusive and in lieu of all others, oral or written, express or implied. No Warn dealer, agent or employee is authorized to make any modification, extension or addition to this warranty.

In no event is Warn responsible for special, incidental or consequential damages resulting from any breach of warranty, or under any other legal theory, including, but not limited to lost profits, down time, goodwill, damage to or replacement of equipment and property, loss of use of the product or of any associated equipment, or cost of substituted products.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Warranty inquiries should be directed to: WARN INDUSTRIES, INC.
Full Floating Axle Customer Service Department
12900 SE Capps Road
Clackamas, Oregon 97015-8903

F N 37786 REV F0